

# Space Station UM-282

(AU, AAX, CLAP, VST2, VST3)

produced by Luca Capozzi (Audiority Srls), January 2022

**Current Manual version: v1.3**

The **Space Station UM-282** is a faithful simulation of the Ursa Major Space Station SST-282, a late 70's echo and reverb unit. Unlike other reverberation devices from that era, the Space Station used delay techniques to transform a mono signal into a new reverberated stereo signal. Where traditional delay units of the past have only one or two taps, the Space Station has many: 8 taps are used for listening and the others are used to synthesize the reverberation. That's why the Space Station has been the secret weapon of many producers and engineers over the years.

Please, read carefully both product specifications and system requirements **before** purchasing any **Audiority** product.

*\*All product names used in this website (www.audiority.com) are trademarks of their respective owners, which are in no way associated or affiliated with Audiority. These trademarks of other manufacturers are used solely to identify the products of those manufacturers whose tones and sounds were studied during Audiority's sound model development. Ursa Major and Space Station SST-282 were originally a trademark of Christopher H. Moore, currently expired to the release date of this product.*

# Space Station UM-282

produced by Audiority, January 2022.

## Credits

Code & DSP: Luca Capozzi (Audiority Srls), Jan 2022

GUI Design: Luca Capozzi

Published by Audiority Srls

Copyright © 2022 – Audiority Srls – All rights reserved.

## Specifications

- Single Multi-tap Delay Line
- 8 Audition Taps
- 16 Audition Delay Programs
- Up to 255ms delay time (extendable to 2.55 secs)
- Up to 3.5s reverb time
- Reduced bandwidth (20Hz-7kHz)
- Echo Sync
- Full Stereo Mode
- Echo Only Mode
- Delay Extension
- Ducking
- Resizable interface

## System Requirements

### PC

- Windows 7 64bit or later
- Intel i5 or equivalent
- 2 GB RAM
- Screen resolution: 1024×768
- CLAP, VST2, VST3, AU 64-bit host
- PT11 or higher, AAX 64-bit host

### MAC (Intel)

- OSX 10.8 or later
- Intel i5 or equivalent
- 2 GB RAM
- Screen resolution: 1024×768
- CLAP, VST2, VST3, AU 64-bit host
- PT11 or higher, AAX 64-bit host

### MAC (Silicon)

- macOS 11.0 or later
- M1 or higher
- 2 GB RAM
- Screen resolution: 1024×768
- CLAP, VST2, VST3, AU 64-bit host
- PT11 or higher, AAX 64-bit host

## FILE LOCATIONS

### Mac

All presets, license, IR files and settings are located in:  
/Users/Shared/Audiority/

AAX and VST plugins will be placed in their own Audiority sub-folder located in:

AAX: /Library/Application Support/Avid/Audio/Plug-Ins/Audiority  
CLAP: /Library/Audio/Plug-Ins/CLAP/Audiority  
VST: /Library/Audio/Plug-Ins/VST/Audiority  
VST3: /Library/Audio/Plug-Ins/VST3/Audiority


### PC

All presets, license, IR files and settings are located to:  
C:\Users\Public\Public Documents\Audiority

AAX and VST plugins will be placed in their own Audiority sub-folder, usually located in:

AAX: C:\Program Files\Avid\Audio\Plug-Ins\Audiority  
CLAP: {Your CLAP Path}\Audiority  
VST: {Your VST Path}\Audiority  
VST3: {Your VST3 Path}\Audiority

## PLUGIN ACTIVATION



Once you install and open the plugin for the first time, it will be in **Demo Mode** until a license file is loaded. In Demo Mode the plugin will output 3 seconds of silence every minute.

You can activate the plugin either OFFLINE or ONLINE.

### OFFLINE ACTIVATION


If you purchased the plugin from our site, you should have received an email to download the installers and the license file. Save the license file you got with your purchase email (or via our User Area) anywhere on your computer.

Then, to activate the plugin, click on the **Audiority** logo and select “**Register**”. The Registration window will pop up allowing you to load the license file you got while purchasing the plugin by clicking the “**Load License**” button. Alternatively, you can drag and drop the license file on the registration window.

**NOTE:** If you purchased the plugin from one of our dealers, please check the “**USER AREA AND REDEEM CODES**” section below.

### ONLINE ACTIVATION

If you are registered to our User Area, then you can activate the plugin online.



Insert your Username (or email address), your password and click the “**Login**” button. The license file will be automatically delivered in your computer and the plugin will be activated.

## USER AREA AND REDEEM CODES

If you purchased from one of our dealers, then you should have received an email with a redeem code. This code is required to deposit a license in your User Area account and let you download the license file or activate the plugin online.

If you don't have an User Area account yet, please follow these steps:

- 1) Go to <https://www.audiority.com/register> and fill out the signup form.

**IMPORTANT:** Please be sure to register with the **e-mail address you use for your purchases**, otherwise your products will not show. Since we use reCAPTCHA for registration only, please temporarily disable any ad blocker you are using.

**Username**

**First Name**


**Last Name**

**Purchase E-mail Address**


**Password**

**Confirm Password**


I read and agree to the Privacy Policy and Terms of Use



2) Once registered, log in to your account by clicking the User Area section of our site. Click the **REDEEM** section of your account and paste the code you received via email from our dealer.




3) After submitting the code, a license will be deposited in your account and will be shown in **“MY PLUGINS”** section of your User Area.



4) Now you can click “License File” and save the license anywhere on your computer and ready to be loaded through the plugin registration window. You can also skip this part and activate your plugin online (see previous section of this manual).


## USER PATHS SETTING



By selecting **“Settings”** from the logo menu, you can change the path for **Presets**, **License** and **IR** folders. You can also disable our Newsfeed from here.

**Note:** Please do not move the **Settings** folder from its default location.

# READ ME FIRST



## SIGNAL PATH

The Space Station uses a single delay line with multiple taps to generate echoes and reverberation. Eight taps are used as Audition Taps, while the others to synthesize the reverberation. The Echo signal comes from a dedicated tap that is mixed along with the Audition Taps. This means that you NEED at least one of the Audition Taps knobs to be above zero to actually get the Echo output. Enable the ECHO ONLY mode to bypass the Audition Taps. In this mode the Space Station will act as a regular delay unit. Input overload occurs with signals over 20V p-p in the machine, while on the plugin should be around +26dB over 0dBFS.

## AUDITION TAPS AND MIXER

The Space Station internal processor has one input, fed from a mixer, where direct and fed-back signals are combined, but has many outputs, named taps. Eight of these taps are called Audition Delay Taps because their sole function is for mixing into the final signal that is returned to the unit. The Audition Taps are never recirculated and have no role in reverberation or echo feedback. The 8 taps are paired and each pair (1&2, 3&4, etc) is returned to a knob in the AUDITION DELAY MIXER. The odd numbered taps are mixed together and sent to the left output, while the even numbered goes to the right output. The DIRECT signal goes to both channels. Use the MIXED / DRY button to mute all the Audition Taps while leaving only the DIRECT signal.

The Audition Taps are set to various delay times by the AUDITION DELAY PROGRAMS buttons. You have several families of programs, ranging from Rooms, Space Echoes up to weird comb filters. Usually, in all programs, the lower number taps have the shorter delay times, with times increasing progressively from Tap 1 to 8.

## ECHO MODE

In Echo Mode (REVERB / ECHO button set to off) the Space Station will behave as a delay. The Echo tap time and feedback can be set via the ECHO DELAY TIME and REVERB ECHO/FEEDBACK knobs. This signal is summed to all the Audition Taps so, for each one of the TAPS knob, you will get the Echo Tap AND the additional echo from the selected taps.


## REVERB MODE

In Reverb Mode (REVERB / ECHO button set to on) the Space Station will behave as a reverb. The Audition Taps works as a sort of early reflections, so changing the AUDITION DELAY PROGRAMS will shape the reverberation response. Use the REVERB / ECHO FEEDBACK knob to set the reverb length. ECHO DELAY TIME has no role when the Space Station is in Reverb mode.

## BREAKING CHANGES FROM v1.1

In v1.1 we introduced two new parameters to improve the matching between the original hardware unit and the plugin: FBK TRIMMER and AGE. **If you have projects made with v1.0, please set FBK TRIMMER TO 50% and AGE to 100%** or your projects will sound differently from what you intended. If you want to match the hardware unit we used to make this plugin, set FBK TRIMMER to 35%, AGE to 7% with **Broken Tap** enabled. For more information about these parameters, please read the next page.

# Plugin Parameters



## TOOLBAR

The Toolbar allows you to manage the plugin presets, register the plugin and set some global parameters.

By clicking the **AUDIORITY** logo, in the top left corner of the Toolbar, you'll be able to visit our website and social profiles, register the plugin, change the interface size and customize the paths for license and preset files.

The **HQ** button will enable oversampling, useful to reduce aliasing when the signal saturates. Use the **Randomize** and **Reset** buttons to experiment with random presets or restoring it to its saved version. Press **CTRL+DOUBLE CLICK** on any knob to manually assign a new value.

## PARAMETERS

<b>INPUT LEVEL</b>	Adjust the incoming signal volume
<b>LF / HF CUT</b>	Cuts the low/high frequencies of the incoming signal. This also affects the relative decay time of the reverberation frequencies
<b>DIRECT TAP</b>	Adjust the volume of the direct signal.
<b>AUDITION TAPS</b>	Adjust the volume of the audition taps. TAPS 1&2 always have the shortest taps, while TAPS 7&8 the longest
<b>REVERB/ECHO FEEDBACK</b>	Adjust the echo feedback or reverb time
<b>ECHO DELAY TIME</b>	Adjust the echo time by 1ms steps
<b>MIXED / DRY</b>	Switches between unprocessed (DIRECT ONLY) and processed (DIRECT + TAPS) signal
<b>REVERB / ECHO</b>	Switches between Echo and Reverberation
<b>AUDITION DELAY PROGRAMS</b>	Selects one of the 16 programs for the Audition Taps. Use the first button on the left to switch between the upper row (ROOMS / COMBS) and the lower row (DELAY / SPACE REPEATS)
<b>REVERB PROGRAM</b>	Switches between the medium and long reverb program. They may sound very similar, but the frequencies build-up is different
<b>PUSH TO SYNC</b>	Enables the tempo sync for the Echo mode
<b>POWER</b>	Powers the unit on/off

## GLOBAL CONTROLS (Footer)

<b>INPUT / OUTPUT</b>	Pre/Post effect gain
<b>FULL STEREO</b>	Process each stereo channel independently
<b>ECHO ONLY</b>	Disables the audition taps to get a more precise echo time
<b>AGE</b>	Decreasing this value will lower the dynamic range and one of the taps amplitude (if enabled). Right click on the knob to set the Broken Tap simulation, resulting in a wider stereo field when AGE is decreased.
<b>FBK TRIMMER</b>	Changes the curve of the feedback potentiometer. Set to 50% to restore v1.0 settings.
<b>DELAY EXT</b>	Increases the max delay time of the plugin. This parameter won't affect the Reverb mode.
<b>DUCKING</b>	Sets the ducking amount related to the current echo delay time
<b>MIX</b>	Dry/wet signal mixer.



### **RESIZING CONTROLS (Audiority logo menu)**

**Small / Default / Big Size**                      Reduce, reset or increase the size of the plugin interface.

**Resizing Corner**                                      You can resize from the bottom right corner of the GUI



#### **IMPORTANT**

This plugin, like the original unit, is a mono to stereo device. When used on a stereo track, both channels will be summed and processed as a mono input. Enable FULL STEREO mode to process each stereo channel independently.

# CHANGELOG

## **v1.3** (Aug 2022)

- NEW: Updated Framework
- NEW: CLAP plugin format (beta)
- NEW: Non-destructive Monophonic Modulations (CLAP only)
- FIX: GUI not showing correct preset name when opened the first time
- FIX: Improved button automations
- FIX: Reverb tail not flushed on transport restart
- CHANGE: Improved error messages

## **v1.2** (Mar 2022)

- NEW: Updated Framework
- NEW: Persistent GUI settings (via Settings option)
- NEW: Drag and Drop license file on registration window
- CHANGE: Broken Tap simulation now must be set via right click on AGE knob.
- BREAKING CHANGE: Broken Tap simulation is OFF by default

## **v1.1.1** (Jan 2022)

- NEW: Input overload saturation
- FIX: FBK TRIMMER causing crash on some configurations
- FIX: Wrong FBK TRIMMER default value for v1.0 saved states and presets
- FIX: Preset folder opened when clicking some specific presets
- FIX: Manual errata corrige

## **v1.1** (Jan 2022)

- NEW: Updated framework
- NEW: Improved hardware matching
- NEW: Age and FBK Trimmer parameters
- NEW: Ctrl+Double Click to set knob value manually
- FIX: Value from text always returning 0
- BREAKING CHANGE: New parameters change the sound behaviour.  
Set both AGE and FBK TRIMMER to 100% on projects saved with v1.0.

## **v1.0** (Jan 2022)

- Original release

## Audiority Srls – EULA (End-User License Agreement)

The software that accompanies this license is supplied under a license agreement. By installing this software you are agreeing to the Audiority License Agreement. If you do not agree with these terms, do not install the software. If you haven't downloaded a license file (or used a redeem code), you may obtain a refund within 14 days through the dealer where you purchased the software, or if purchased at any of Audiority online stores, by contacting support@audiority.com.

The terms of this license agreement are as follows:

By installing the software, you confirm your acceptance of the Audiority Srls End User License Agreement. This is a non-exclusive, single-user License.

This End User License Agreement ("Agreement") is between Audiority Srls and you.  
IMPORTANT – PLEASE READ THIS LICENSE AGREEMENT CAREFULLY BEFORE INSTALLING THIS SOFTWARE.

By using the Audiority Srls Software you accept these terms. The Audiority Srls Software may be distributed with software or components from third-parties ("Third-Party Software"). Use of Third-Party Software is also subject to the terms of this EULA.

### 1. Limited Use License.

The Software is licensed, not sold, by Audiority or its Third-Party Software suppliers ("Suppliers") to the original end user for use only on the terms set forth in the Agreement. If and only if your Software is purchased through a Audiority Authorized Dealer or Distributor, Audiority, as Licensor, grants you, as an end user Licensee, a non-exclusive license to use the Software (which includes computer software, updates and any bug fixes subsequently delivered and associated media, printed materials and "online" or electronic documentation).

### 2. Title.

The Software is owned by Audiority or its Suppliers as applicable, and is protected by copyright laws and international treaty provisions, as well as other intellectual property laws and treaties. Audiority (or its Suppliers, as applicable) retains title to and ownership of the Software and all copies, as well as any rights not specifically granted. This Agreement only gives you certain rights to use the Software and related documentation, which may be revoked if you do not follow these terms.

### 3. Limited Rights to Install and Use the Software.

#### (i) Permitted use and restrictions.

You may install the Software into the memory of no more than three computers for your internal business use or your own personal enjoyment, but may not redistribute or electronically transfer the Software to someone else's computer or operate it in a time-sharing or service-bureau operation.

#### (ii) Reverse engineering and copying limitations.

You may make one copy of the Software for backup purposes only (and replacement backup copies in the event of loss of or damage to a backup copy), provided you include all copyright notices contained on the original media on the backup copy. You may not modify, translate, adapt, reverse engineer, decompile, create other works from, or disassemble the Software or any portions thereof (except and to the extent that applicable law expressly permits reverse engineering, decompilation or disassembly).

#### (iii) Technical limitations.

The Software may include technological measures that are designed to prevent or detect unlicensed use of the Software. Circumvention of these technological measures is prohibited, except and only to the extent that applicable law expressly permits, despite this limitation. Any attempt to circumvent technical limitations may render the Software or certain features unusable or unstable, and may prevent you from updating or upgrading the Software.

#### (iv) No reconfiguration.

The Software is licensed for installation and use only in the manner it was provided to you, as configured by an automated installation program provided with the Software, or as described in Audiority's Documentation. You may not separate the components contained in the Software or otherwise reconfigure the Software to circumvent technical limitations on the use of the Software or to otherwise exceed the scope of your license.

### 4. Export and Renting Restrictions.

You may not export, convey, rent, sublicense, or otherwise distribute the Software or any rights therein to any person or entity.

### 5. License Transfer.

Except if otherwise stated within this EULA, Licensee may resell the software to a third party or transfer the software permanently if the Licensee purchased the Software from any Audiority store or from any Audiority Dealer. Audiority reserves all rights to deny any requests for the transfer of this license, and may institute transfer fees and policies as it sees fit at the time of any request for the transfer of this license, if the Licensee purchased the license from another Licensee. By transferring a license, the third party agrees in writing with this EULA and Licensee ceases all use of the software, completely removes all installed copies of the software from its computer and – if the software was not purchased via download – deletes or transfers the original data storage to the third party (if Licensee is not obliged to a longer storage by law). NFR (not for resale) copies, including freeware products, free bonus products, and giveaway copies, cannot be resold. Following respective request from Licensee via its email address registered with Audiority, and payment of the Transfer Fee, the license file of the Product will be transferred by Audiority to the third party, and at the same time the registration of Licensee for the software purchased will be deleted. The current and updated Transfer Fee can be found at this address <https://www.audiority.com/faq/#1509113035751-cec03c9c-5c77>

### 6. Excluded Products.

Audiority and its Suppliers give NO warranty for Software free of charge, including Software designated as "demo", "limited release," "pre-release," "loan," "beta" or "test." This Software is provided "AS IS."

### 7. Limitation of Liability.

AUDIORITY AND ITS SUPPLIERS SHALL HAVE NO LIABILITY TO YOU WHETHER IN CONTRACT, TORT, NEGLIGENCE OR PRODUCTS LIABILITY, FOR ANY CLAIM, LOSS, OR DAMAGE, INCLUDING BUT NOT LIMITED TO LOST PROFITS, LOSS OF USE, BUSINESS INTERRUPTION, LOST DATA, OR LOST FILES, OR FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND OR NATURE WHATSOEVER ARISING OUT OF OR IN CONNECTION WITH THE USE OF OR INABILITY TO USE THE SOFTWARE OR DOCUMENTATION, OR THE PERFORMANCE OR OPERATION OF THE SOFTWARE, EVEN IF AUDIORITY OR ITS SUPPLIERS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. IN NO EVENT SHALL AUDIORITY'S TOTAL LIABILITY TO YOU FOR ALL DAMAGES, LOSSES, AND CAUSES OF ACTION WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE) OR OTHERWISE EXCEED THE AMOUNT PAID BY YOU FOR THE SOFTWARE.

8. Termination.

To the extent permitted by law, and without prejudice to any other rights Audiority may have, Audiority may terminate your license if you materially breach these terms and conditions.

9. Third-Party Software and Information.

This EULA governs any Third-Party Software distributed by Audiority. Audiority may include information about third party products and services, including links to Web sites run by others. Audiority is not responsible for, and does not endorse or sponsor, this third-party information.

10. Miscellaneous.

This Agreement constitutes the entire agreement between the parties with respect to the use of the Software and Documentation, and supersedes all prior or contemporaneous understandings or agreements, written or oral, regarding such subject matter. No amendment to or modification of this Agreement will be binding unless in writing and signed by a duly authorised representative of Audiority.

Should you have any questions concerning this Agreement, please contact Audiority Srls at [info@audiority.com](mailto:info@audiority.com)

Copyright ©2010-2022 Audiority Srls. All rights reserved.

Last updated on May 19th, 2021

# Thank You

We wanna thank you for buying **Audiority Space Station UM-282** plugin.

We hope you will enjoy it as much as we did.

If you have any question, concerns, technical issues or even for just say 'Hello', get in touch with us at:

[info@audiority.com](mailto:info@audiority.com)

or checkout our site at [www.audiority.com](http://www.audiority.com)

Cheers,  
Luca

**Follow us on:**

[Facebook](#)

[Twitter](#)

[SoundCloud](#)

[YouTube](#)

[Instagram](#)

**Official Facebook Support:**

[Audiority Audiophiles](#)

**Audiority User Area: (registration is required to access the UA and download installers and license files)**

[Audiority User Area](#)

